

# Clock (Repeater)

## RTLS cable synchronization source

- 7 ports (expandable by Repeater)
- Up to 35 Anchors connected
- Included Ethernet switch
- PoE



**Clock Distributor.** One clock distributor is needed per installation. Power supply is 100W, 57 V DC. It is possible to connect up to 35 anchors to this device in mixed star – chain topology (7 ports, and up to 5 anchors in chain). In case of large system, clock repeaters are required. Clock signal can be distributed without amplification for over 100 meters. Clock has built-in 8 port Ethernet switch. One connection cable with synchronization, Ethernet, Power over Ethernet (up to 100 m length).

**Clock Repeater.** Required for systems with more than 35 anchors. Repeaters can be cascaded to get required structure of the anchors placement. By using repeaters, large systems with hundreds of anchors are possible.

<b>Dimensions</b>	43 x 4,45 x 20 cm Rack 19" 1U
<b>Server Connection</b>	Ethernet
<b>Anchor Connection</b>	Ethernet, Synchronization, PoE
<b>Cable Length</b>	Up to 100 m
<b>Ports</b>	7
<b>Max connected</b>	35 Anchors or Repeaters

